

Installation Instructions Concrete Floor Boxes series CF9 and CF10

CF series boxes come completely assembled with device plates and mud cap in place. Finish cover assembly supplied loose.

Minimum pour depth shall be box height plus 1/16".

To install:

- 1) Position and adjust height and level box using the 4 (four) corner levelling screws provided.**
- 2) Install conduit to box through the 1/2- 3/4 " conduit knock outs on the appropriate position on the end of the box.**
- 3) Install mud cap provided with box.**
- 4) After pour remove device plates and install devices and wire as specified.**
- 5) Re install device plates and install cover assembly.**